



Position of Parts in Engine Compartment (LHD 1KD-FTV, 2KD-FTV)

- * 3:1KD-FTV
- * 4:2KD-FTV
- * 5:5M/T
- * 6:6M/T




C1	Transmission Revolution Sensor (NT)
C2	Transmission Revolution Sensor (SP2)
C3	Compressor Assembly
C7	Differential Motor Actuator Assembly
C8	Engine Oil Pressure Switch Assembly
C10	Generator Assembly
C19	Fuel Injector Assembly No. 2
C21	Fuel Injector Assembly No. 4
C24	Park/Neutral Position Switch Assembly
C32	Starter Assembly
C41	Transfer Shift Actuator Assembly
C51	Back-Up Light Switch Assembly
C62	Speedometer Sensor
C72	Glow Plug Assembly
C73	Intake Air Temperature Sensor
C74	Generator Assembly
C75	Diesel Throttle Body Assembly
C76	Diesel Throttle Body Assembly
C78	Fuel Temperature Sensor
C79	Cam Position Sensor (No. 2 Crank Position Sensor)

Position of Parts in Engine Compartment (LHD 1KD-FTV, 2KD-FTV)




90980-11156




90980-11156





90980-11271




90980-11858




90980-11363




90980-11875




90980-11875




90980-12362




90980-11400





90980-11664




90980-11051




90980-11143



90980-11025



90980-11964



90980-11145



90980-11261



90980-10737



90980-10947