






















Position of Parts in Engine Compartment (RHD 1TR-FE, 2TR-FE)



C1	Transmission Revolution Sensor (NT)
C2	Transmission Revolution Sensor (SP2)
C3	Compressor Assembly
C7	Differential Motor Actuator Assembly
C8	Engine Oil Pressure Switch Assembly
C9	Generator Assembly
C10	Generator Assembly
C11	Throttle Body with Motor Assembly
C16	Purge VSV
C18	Fuel Injector Assembly No. 1
C19	Fuel Injector Assembly No. 2
C20	Fuel Injector Assembly No. 3
C21	Fuel Injector Assembly No. 4
C24	Park/Neutral Position Switch Assembly
C28	Power Steering Oil Pressure Switch
C31	Oxygen Sensor (Bank 1 Sensor 2)
C32	Starter Assembly
C33	Ignition Coil Assembly No. 1
C34	Ignition Coil Assembly No. 2
C35	Ignition Coil Assembly No. 3
C36	Ignition Coil Assembly No. 4
C41	Transfer Shift Actuator Assembly
C42	ECT Solenoid (Transmission Wire)
C45	E.F.I. Engine Coolant Temperature Sensor
C49	Air Fuel Ratio Sensor (Bank 1 Sensor 1)
C50	Camshaft Timing Oil Control Valve Assembly (Exhaust Side)
C51	Back-Up Light Switch Assembly
C61	Crank Position Sensor
C62	Speedometer Sensor
C63	Camshaft Timing Oil Control Valve Assembly (Intake Side)
C64	VVT Sensor (Exhaust Side)
C65	VVT Sensor (Intake Side)
C69	Air Injection Control Driver
C70	Air Pressure Sensor
C71	Air Switching Valve Assembly

Position of Parts in Engine Compartment (RHD 1TR-FE, 2TR-FE)



Position of Parts in Engine Compartment (RHD 1TR-FE, 2TR-FE)




90980-10735




90980-11178




90980-11162




90980-11051




90980-11016




90980-11143




90980-11162




90980-12353




90980-12353



90980-11858



90980-10845



90980-11149