



Position of Parts in Engine Compartment (RHD 1GR-FE)




C1	Transmission Revolution Sensor (NT)
C2	Transmission Revolution Sensor (SP2)
C3	Compressor Assembly
C4	Air Fuel Ratio Sensor (Bank 1 Sensor 1)
C5	Air Fuel Ratio Sensor (Bank 2 Sensor 1)
C6	VSV (ACIS)
C7	Differential Motor Actuator Assembly
C8	Engine Oil Pressure Switch Assembly
C9	Generator Assembly
C10	Generator Assembly
C11	Throttle Body with Motor Assembly
C19	Fuel Injector Assembly No. 2
C21	Fuel Injector Assembly No. 4
C22	Fuel Injector Assembly No. 5
C23	Fuel Injector Assembly No. 6
C24	Park/Neutral Position Switch Assembly
C25	Cam Timing Oil Control Valve Assembly RH (Bank 1)
C26	Cam Timing Oil Control Valve Assembly LH (Bank 2)
C27	Crank Position Sensor
C28	Power Steering Oil Pressure Switch
C30	No. 2 Oxygen Sensor (Bank 2 Sensor 2)
C31	Oxygen Sensor (Bank 1 Sensor 2)
C32	Starter Assembly
C33	Ignition Coil Assembly No. 1
C34	Ignition Coil Assembly No. 2
C35	Ignition Coil Assembly No. 3
C36	Ignition Coil Assembly No. 4
C37	Ignition Coil Assembly No. 5
C38	Ignition Coil Assembly No. 6
C41	Transfer Shift Actuator Assembly
C42	ECT Solenoid (Transmission Wire)
C43	VVT Sensor (Bank 2 Intake Side)
C44	VVT Sensor (Bank 1 Intake Side)
C45	E.F.I. Engine Coolant Temperature Sensor
C122	Purge VSV
C123	Fuel Injector Assembly No. 1
C124	Fuel Injector Assembly No. 3

Position of Parts in Engine Compartment (RHD 1GR-FE)



90980-11156



90980-11156




90980-11271




90980-10869



90980-10869




90980-11149





90980-11858




90980-11363




90980-12A88




90980-11858




90980-11875




90980-11875



90980-11875



90980-11875




90980-12362




90980-11162




90980-11162



90980-12028




90980-11428




90980-11028




90980-11028




90980-11400




90980-11885




90980-11885




90980-11885



90980-11885



90980-11885



90980-11885

Position of Parts in Engine Compartment (RHD 1GR-FE)

