


Position of Parts in Body (LHD Single Cab)



* 1:w/ Power Window (Driver's Door Only Jam Protection)
* 2:w/o Power Window (w/o Jam Protection)

Position of Parts in Body (LHD Single Cab)

J1	Front Door Lock Assembly RH
J2	Front Power Window Regulator Motor Assembly RH
J3	Outer Rear View Mirror Assembly RH
J4	Front No. 1 Speaker Assembly RH
J5	Front Power Window Regulator Switch Assembly RH
J10	Door Side Airbag Sensor RH
K1	Front Door Lock Assembly LH
K2	Front Power Window Regulator Motor Assembly LH
K3	Outer Rear View Mirror Assembly LH
K4	Front No. 1 Speaker Assembly LH
K5	Power Window Regulator Master Switch Assembly
K9	Front Power Window Regulator Motor Assembly LH
K10	Door Side Airbag Sensor LH
K11	Outer Mirror Switch Assembly
K12	No. 45 Junction Connector

Position of Parts in Body (LHD Single Cab)

