





G122 Eco Run Cancel Switch Assembly
G123 Pre-Collision System Cancel Switch Assembly
G124 Lane-Keeping Assist Main Switch
G125 Engine Stop and Start ECU
G126 Engine Stop and Start ECU
G127 Engine Stop and Start ECU
G128 Network Gateway ECU
G129 Pre-Collision City Buzzer
G130 Telephone Transceiver Assembly
G131 No. 3 CAN Junction Connector
G132 No. 4 CAN Junction Connector
G133 No. 4 CAN Junction Connector
G135 No. 4 CAN Junction Connector
G138 Key Cylinder Light Assembly
G139 Spiral Cable Sub-Assembly
G140 Steering Heater Switch
G194 Refreshing Seat Switch RH
G196 A/C Amplifier Assembly
G198 Diesel Particulate Reduction Switch Assembly


Position of Parts in Instrument Panel (LHD)

G122
Black




90980-12551
(Before Aug. 2017 Production)

G122
White




90980-12551
(From Aug. 2017 Production)

G123
Black




90980-12551

G124
Black




90980-12550

G125
Black




90980-11362

G126
White




90980-12566

G127
Black




82824-12510

G128
Black




90980-12912

G129
Blue




90980-10860

G130
White




90980-12817

G131
White




90980-12A58


Position of Parts in Instrument Panel (LHD)




90980-12355




90980-12355




90980-12355




90980-12092




90980-12A94




90980-12614



90980-12368



90980-12555



90980-12552