



Position of Parts in Instrument Panel (RHD)

- * 1: Refer to the Service Bulletin for the installation position of the parts.
- * 28: w/ Idle Switch
- * 29: w/ Viscous Heater




G70	Certification ECU
G71	Steering Lock Actuator or Upper Bracket Assembly
G72	Downhill Assist Control Switch
G74	No. 1 Indoor Electrical Key Antenna Assembly
G75	Idle Up Switch
G76	Heater Switch Assembly
G78	Quick Heater Assembly
G79	Quick Heater Assembly
G81	Engine Switch
G89	Transmission Control ECU Assembly
G90	Transmission Control ECU Assembly
G93	No. 26 Junction Connector
G94	No. 27 Junction Connector
G95	No. 28 Junction Connector
G96	No. 29 Junction Connector
G97	No. 30 Junction Connector
G98	No. 31 Junction Connector
G99	No. 32 Junction Connector
G100	No. 33 Junction Connector
G101	No. 34 Junction Connector
G102	No. 35 Junction Connector
G103	No. 36 Junction Connector
G104	No. 36 Junction Connector
G105	No. 37 Junction Connector
G106	No. 38 Junction Connector
G107	No. 39 Junction Connector
G108	No. 40 Junction Connector
G109	No. 41 Junction Connector
G111	No. 42 Junction Connector


Position of Parts in Instrument Panel (RHD)




90980-12708




90980-12092




90980-12366




90980-12795




90980-12550




90980-12366




90980-10903




90980-10956




90980-12361




90980-12560




90980-12561




90980-12B54



90980-12B54




90980-12B54



90980-12B54


Position of Parts in Instrument Panel (RHD)

G97
Black




90980-12B54

G98
Black




90980-12B54

G99
Black




90980-12B54

G100
Black




90980-12B54

G101
Black




90980-12B54

G102
Black




90980-12B54

G103
White




90980-11661

G104
White




90980-11661

G105
Black



90980-12B54

G106
Black



90980-12B54

Position of Parts in Instrument Panel (RHD)

