D RELAY LOCATIONS

: Center J/B | Near The Steering Column Tube (See Page 27)

[RHD Australia]

