

Power Source | Ignition (2RZ-FE)

1 | 2



LHD

3 4


L-B
* 1 : w/ Daytime Running Light
* 2 : w/o Daytime Running Light
* 3 : 70A Type Alternator
* 4 : 45A, 55A Type Alternator
From Daytime Running Light Relay(*1)<203-4> From HEAD Relay(*2) <206-2>
To Combination SW <203-4><206-1>
J18 JUNCTION CONNECTOR
R-W
L-W
3 B
4 HR
5 LH
R 3 REAR FOG LIGHT SW
E
L
7
1
W-B
Y-G
J19 JUNCTION CONNECTOR
J14 JUNCTION CONNECTOR
J 7 JUNCTION CONNECTOR
C10 REAR FOG LIGHT INDICATOR LIGHT [COMB. METER]
6
10
R 9 REAR FOG LIGHT
BC1
J23 JUNCTION CONNECTOR
IG
Cowl side panel LH
Cowl side panel RH