

F ELECTRICAL WIRING DIAGRAM (System Circuits)



RHD


3
4
B–R
(General)
B
B
J13 A, J14 B
JUNCTION CONNECTOR
B
A
B–R
10 IC5
B–R
(1RZ)
(3RZ–F)
B–R
B–R
1
I 4
IGNITION COIL NO. 1
2
1
I 5
IGNITION COIL NO. 2
2
B–R
L
Y
L
(Shielded)
3
5
1
4
B
C
P+
P–
BR
IGV
EX
2
6
I 1
IGNITER
B
B
4 IC5
B
B
B
B–L
B
To Emission Control ECU <311–3>
To Tachometer [Comb. Meter] <392–1>
To A/C Amplifier <399–3>
BR
EE
Cylinder block right side
B–R
1 C
I 6 C
IIA
4 C
2 C
B
B
4 IC5
B–L
B
B
To Emission Control ECU<311–3>
To Tachometer [Comb. Meter] <392–1>

RHD