D RELAY LOCATIONS

: Center J/B	Near the Steering Column Tube (See Page 23)

[RHD Australia]

