
D RELAY LOCATIONS

⑥ : R/B No.6	Radiator Support RH (See Page 23)

[RHD w/ Dim–Dip Light]



⑦ : Passenger Side R/B	Cowl Side Panel LH (See Page 23)

[RHD 3RZ–FE, 1RZ–E, 1KZ–TE]

