
Position of Parts in Body

[RHD : Extra Cab]



A 28 ABS Speed Sensor Rear LH
A 29 ABS Speed Sensor Rear RH

D 16 Door Key Lock and Unlock SW
D 17 Door Lock Control SW
D 18 Door Lock Motor Front LH
D 19 Door Lock Motor Front RH
D 22 Door Speaker Front LH
D 23 Door Speaker Front RH

F 12 Fuel Pump
F 13 Fuel Sender

I 20 Interior Light

L 1 License Plate Light LH
L 2 License Plate Light RH

P 14 Pretensioner LH
P 15 Pretensioner RH

R 6 Rear Combination Light LH
R 7 Rear Combination Light RH
R 10 Rear Window Defogger
R 11 Rear Window Defogger