

(Cont. next page)
56 HILUX (RHD)
Power Source
Engine Control (1KZ–TE)
J12 JUNCTION CONNECTOR
C 3 CHECK CONNECTOR
V10 VRV(EGR)
T 5 TIMING CONTROL VALVE
V13 VSV(Intake Constrictor Control No. 1)
V14 VSV(Intake Constrictor Control No. 2)
ENGINE ECU
F14 FIRST GEAR POSITION SW
J 3 JUNCTION CONNECTOR
Cowl side panel LH
Cylinder block
C15 CRANKSHAFT POSITION SENSOR
E 7 ENGINE SPEED SENSOR
S 9 SPILL CONTROL VALVE
SPILL CONTROL VALVE RELAY
ECD RELAY
SUB GLW RLY
J1, J2 JUNCTION CONNECTOR
Front right fender apron
G 1 GLOW PLUG
I17 IGNITION SW
80A ABS, GLOW
15A ECD
30A AM2
40A AM1
100A ALT
BATTERY

56 HILUX (RHD) (Cont' d)

