
④ : Engine Room R/B No.2	LHD Diesel : Engine Compartment Left (See Page 8) RHD Diesel : Engine Compartment Right (See Page 9)



⑤ : R/B No.5	LHD : Front Right Fender Apron (See Page 8) RHD : Near the Brake Master Cylinder (See Page 9)

