
Position of Parts in Instrument Panel

[RHD]



A 13 A/C Amplifier
A 14 A/C SW
A 15 A/C Thermistor
A 16 A/C Volume SW
A 17 ABS Deceleration Sensor
A 18 ABS ECU
A 19 ABS ECU
A 20 ADD Control Relay
A 24 Airbag Squib (Front Passenger's Airbag Assembly)
A 25 Airbag Squib (Steering Wheel Pad)
A 26 Ashtray Illumination
A 27 Auto Antenna Control Relay
A 31 Accelerator Pedal Position Sensor
A 32 Accelerator Pedal SW
A 33 A/C Lock Detection Amplifier

B 4 Blower Motor
B 5 Blower Resistor
B 6 Blower SW

C 5 Cigarette Lighter
C 6 Cigarette Lighter Illumination
C 8 Clock
C 9 Combination Meter
C 10 Combination Meter
C 11 Combination Meter
C 12 Combination SW
C 13 Combination SW
C 14 Combination SW
C 16 Center Airbag Sensor Assembly
C 17 Center Airbag Sensor Assembly
C 18 Center Airbag Sensor Assembly

D 4 Diff. Lock ECU
D 5 Diff. Lock SW
D 6 Dim–Dip Light Relay
D 7 Diode (Door Courtesy)
D 8 Diode (Glow Plug)
D 9 Diode (Idle–Up)
D 10 DLC3
D 11 Door Courtesy SW Front LH
D 12 Door Courtesy SW Front RH