
## Connector Joining Wire Harness and Wire Harness




| Code | Joining Wire Harness and Wire Harness (Connector Location) |
|---|---|
| EA1 | Engine Room No.2 Wire and Engine Room Main Wire (Front Right Fender Apron) |
| EB3 | Engine No.2 Wire and Engine Room Main Wire (Near the Engine Room R/B) |
| ED1 | Engine No.2 Wire and Differential Wire (Near the Starter) |