

OVERALL ELECTRICAL WIRING DIAGRAM




67 HILUX (RHD) (Cont' d)
ECT and A/T Indicator (5VZ–FE)
D26 Detection SW (Transfer Neutral Position)
J 4 Junction Connector
J 3 Junction Connector
Cowl Side Panel LH
J15 Junction Connector
Cowl Side Panel RH
N 1 Neutral Start SW
A/T P
C 9(A), C10(B), C19(D) Combination Meter
O/D OFF
A/T Oil Temp.
ECT PWR
O 2 O/D Main SW
10A GAUGE
E11 ECT Pattern Select SW
PWR
NORM
J 4 Junction Connector
J 4 Junction Connector
J 4 Junction Connector