INTERIOR

■ SEATS


- 3 types of front seats are available: the bench seat, 60/40 split bench seat and separate seat. The availability of the front seat is as follows:

●: Standard ○: Option

Seat Type / Destination	Cab Type	Bench Seat	60/40 Split Bench Seat	Separate Seat
Europe	Regular Cab	●		●*1,2, ○
	Extra Cab			●
	Double Cab	●		●*1,3,4, ○
Australia	Regular Cab	●*5,6	●*7, ○*6	○
	Extra Cab			●
	Double Cab			●
G.C.C. Countries	Regular Cab	●		
	Double Cab	●		
General Countries	Regular Cab	●		○*8
	Extra Cab			●
	Double Cab	●		●*3, ○


*1: RHD Model
*2: Models for Germany
*3: SR Grade Model
*4: Models for Austria and Israeli
*5: 1RZ-E Engine Model
*6: 4WD Model with 3RZ-FE or 5L Engine
*7: 2WD Model with 3RZ-FE or 5L Engine
*8: Except RZN148L-TRMDK3

- The extra cab model equipped with jump seats provides a walk-in mechanism in the front passenger seat.
- The front seat heater is available as an option on the LHD extra and double cab models with separate seat for Europe.
- The double cab model with separate seats can be arranged to form a full-flat seat arrangement.
- The rear seat with head rest is standard equipment on the double cab SR grade model and optional equipment on the double cab DLX grade model.
- The rear-seatless is an optional equipment for the LN165L-PRMDXW.



140IN42

Extra Cab Model



140IN20

Double Cab Model