INTERIOR

■ SEAT BELTS

The front and rear seat belts are provided as described in the table below. The models with the SRS airbag system are provided with a front seat belt mechanism that contains a seat belt pretensioner and force limiter.

▶ Front Seat Belt ◀

●: Standard ○: Option

Seat Belt / Destination	Seat Type	3-Point ELR*1 for Driver and Passenger Seats	3-Point ELR for Driver and Passenger Seats, and 2-Point NR*2 for Center Seat	3-Point ELR for Driver Seat, 2-Point NR for Center seat and 3-Point ELR with ALR*3 for Passenger Seat
Europe	Bench Seat	●		
	Separate Seat	●		
Australia	Bench Seat		●	
	60/40 Split Bench Seat		●	
	Separate Seat	●		
G.C.C. Countries	Bench Seat		●	○*4
General Countries	Bench Seat	○	●	
	Separate Seat	●		

*1: ELR (Emergency Looking Retractor)
*2: NR (Non-Retractor)
*3: ALR (Auto-Locking Retractor)
*4: Regular Cab Model

▶ Rear Seat Belt ◀

●: Standard ○: Option

Set Belt / Destination	Cab Type	3-Point ELR for Outside seat	3-Point ELR for Outside Seat and 2-Point NR for Center Seat	3-Point ELR with ALR for Outside Seat and 2-Point NR for Center Seat
Europe	Extra Cab	●*1		
	Double Cab		●*2	
Australia	Extra Cab	●*1		
	Double Cab		●	○
G.C.C. Countries	Double Cab		●	○
General Countries	Extra Cab	○		
	Double Cab		○	

*1: Models with Jump Seats
*2: Except Models without Rear Seat