
■FUEL SYSTEM

1. General


- Fuel is supplied under pressure by an electric fuel pump from the fuel tank through the fuel filter to the injectors.
- A quick connector is used to connect the fuel filter and the fuel hose together to improve serviceability.



140EG28

2. Fuel Injector

A compact 4-hole type fuel injector has been adopted to improve the atomization of fuel.



210EG53