

FIRST AND REVERSE BRAKE
COMPONENTS

AT0J8-01





FIRST AND REVERSE BRAKE INSPECTION

AT0J7-02

INSPECT DISC, PLATE AND FLANGE

Check to see if the sliding surface of the disc, plate and flange are worn or burnt. If necessary, replace them.

HINT:

- If the lining of the disc is peeling off or discolored, or even if a part of the printed numbers are defaced, replace all discs.
- Before assembling new discs, soak them in ATF for at least 15 minutes.