FUEL SYSTEM

PRECAUTION


EG0UP-05

1. Disconnect the negative (–) terminal cable from battery.
2. When working on the fuel system, keep away from possible fire hazards and do not smoke.
3. Keep gasoline off rubber or leather parts.
4. Work on only one component group at a time to help avoid confusion between similar looking parts.
5. Keep work area clean to avoid contamination of the carburetor and components.
6. Be careful not to mix up or lose clips or springs.

PREPARATION

SST (SPECIAL SERVICE TOOLS)

EG0UQ-05

	09240–00014	Carburetor Adjusting Gauge Set	
	09240–00020	Wire Gauge Set	
	09243–00020	Idle Adjusting Screw Wrench	
	09922–00010	Wrench 5 x 12 mm	

RECOMMENDED TOOLS

EG0UR-04

	09082–00040	TOYOTA Electrical Tester.	
	09200–00010	Engine Adjust Kit .	
	09860–11011	Carburetor Driver Set.	

EQUIPMENT

EG0US-04

Torque wrench	