


ENGINE FUEL

SST (Special Service Tools)


PP0DL–01

	09228–64030	Fuel Filter Wrench	Europe
	09228–64040	Fuel Filter Wrench	Except Europe
	09236–00101	Water Pump Overhaul Tool Set	
	(09237–00070)	Shaft "C"	Governor sleeve plug
	09260–54012	Injection Pump Tool Set	
 I00830	(09269–54020)	Socket 14 mm	

PP

PP0DM–01

RECOMMENDED TOOLS

	09040–00010 Hexagon Wrench Set .	
	09082–00040 TOYOTA Electrical Tester.	

PP0DN–01

EQUIPMENT

Angle gauge	
Brass brush	Injection nozzle
Dial indicator with magnetic base	
Graduated cylinder	
Injection nozzle tester	
Injection pump tester	
Inner pressure gauge	
Micrometer	
Steel square	
Timer measuring device	
Torque wrench	
Vernier calipers	

PP00D-01

SSM (Service Special Materials)

08833–00080	Adhesive 1344 THREE BOND 1344 LOCTITE 242 or equivalent	Diaphragm push rod