
LUBRICATION

SST (Special Service Tools)

PP0LD–01

	09223–50010	Crankshaft Front oil Seal Replacer	
	09228–07501	Oil Filter Wrench	
	09816–30010	Oil Pressure Switch Socket	

PP0LE-01

RECOMMENDED TOOLS

	09200–00010 Engine Adjust Kit .	

PP0LF-01

EQUIPMENT

Oil pressure gauge	
Precision straight edge	Oil pump
Torque wrench	

PP0LG-01

LUBRICANT

Item	Capacity	Classification
Engine oil		API grade SH, Energy–Conserving II or SJ Energy–Conserving or ILSAC multigrade engine oil. Recommended viscosity is as shown in the illustration.
2WD		
Dry fill	5.1 liters (5.4 US qts, 4.5 Imp. qts)	
Drain and refill		
w/ Oil filter change	4.7 liters (5.0 US qts, 4.1 Imp. qts)	
w/o Oil filter change	4.0 liters (4.2 US qts, 3.5 Imp. qts)	
4WD		
Dry fill	6.3 liters (6.7 US qts, 5.5 Imp. qts)	
Drain and refill		
w/ Oil filter change	6.0 liters (6.3 US qts, 5.3 Imp. qts)	
w/o Oil filter change	5.3 liters (5.6 US qts, 4.7 Imp. qts)	

PP0LH-01

SSM (Service Special Materials)

08833–00080	Adhesive 1344 THREE BOND 1344 LOCTITE 242 or equivalent	Oil pressure switch