


PROPELLER SHAFT

PFCAH-02

SST (Special Service Tools)

	09325–20010	Transmission Oil Plug	2–Joint Type
	09325–40010	Transmission Oil Plug	3–Joint Type
	09330–00021	Companion Flange Holding Tool	Flange
	09332–25010	Universal Joint Bearing Remover & Replacer	
	09950–30010	Puller A Set	Flange
	(09951–03010)	Upper Plate	
	(09953–03010)	Center Bolt	
	(09954–03010)	Arm	
	(09955–03030)	Lower Plate 130	
	(09956–03020)	Adapter 18	

PP0AJ-02

EQUIPMENT

Dial indicator	
Torque wrench	