






AIR CONDITIONING

SST (Special Service Tools)


PP0JK-01

	*07110–58060*	*Air Conditioner Service Tool Set*	
	(07117–58060)	Refrigerant Drain Service Valve	
	(07117–58070)	T–Joint	
	(07117–58080)	Quick Disconnect Adapter	
	(07117–58090)	Quick Disconnect Adapter	
	(07117–88060)	Refrigerant Charging Hose	
	(07117–88070)	Refrigerant Charging Hose	
	(07117–88080)	Refrigerant Charging Hose	
	07112–15020	Seal Plate Remover	
	07112–66040	Magnetic Clutch Remover	
	07112–76060	Magnetic Clutch Stopper	
	07112–85010	Lip Seal Protector	

	07112–85030	Lip Seal Remover	
	07114–84010	Snap Ring Pliers	
	07114–84020	Snap Ring Pliers	
	07116–38360	Gas Leak Detector Assembly	

RECOMMENDED TOOLS

PP094-01

	09082–00040	TOYOTA Electrical Tester.	
	09216–00021	Belt Tension Gauge .	
	09216–00030	Belt Tension Gauge Cable .	

PP095–02

EQUIPMENT

Voltmeter	
Ammeter	
Ohmmeter	
Test lead	
Thermometer	Thermistor
Torque wrench	
Thickness gauge	Magnetic clutch
Plastic hammer	Magnetic clutch
Hexagon wrench	Expansion valve

PP096–01

LUBRICANT

Item	Capacity	Classification
Compressor oil	–	ND–OIL 8 or equivalent
When replacing receiver	20 cc (0.71 fl.oz.)	
When replacing condenser	40 cc (1.4 fl. oz.)	
When replacing evaporator	40 cc (1.4 fl. oz.)	