
# STARTING

## RECOMMENDED TOOLS

PP0DU–03

| | | |
|---|---|---|
|  | 09082–00040 TOYOTA Electrical Tester. | |