STEERING

TORQUE SPECIFICATION

SS0AV–03

Part tightened	N·m	kgf·cm	ft·lbf
STEERING COLUMN			
Non–tilt steering column:			
Column tube support x Column tube	20	204	15
Sliding yoke x Main shaft assembly	35	360	26
Tilt steering column:			
Tilt lever assembly lock nut	12	125	9
Tilt support No.1 reinforce set bolt	5.4	55	48 in.·lbf
Steering support x Column tube	9.5	97	84 in.·lbf
Sliding yoke x Main shaft assembly	35	360	26