
ENGINE

DI31H–05

HOW TO PROCEED WITH TROUBLESHOOTING

Troubleshoot in accordance with the procedure on the following page.



Titles inside ▱ are titles of pages in this manual, with the page number indicated in the bottom portion. See the indicated pages for detailed explanations.

Step 2, 3, 5, 10, 13: Diagnostic steps permitting the use of the hand–neld tester or break–out box.