INJECTION PUMP

FU06Y–01

ON–VEHICLE INSPECTION

1. INSPECT ENGINE SPEED SENSOR (See page ED–20)
2. INSPECT SPILL CONTROL VALVE (See page ED–9)
3. INSPECT INJECTION PUMP CORRECTION RESISTORS (See page ED–24)
4. INSPECT TIMING CONTROL VALVE (See page ED–8)