

































ENGINE MECHANICAL



PP2D0–01

SST (Special Service Tools)

	09992–00500	Compression Gauge Attachment	
	09992–00025	Cylinder Compression Check Gauge Set	
	(09992–00200)	L Joint	
	(09992–00211)	Gauge Assy	
	09248–64011	Valve Clearance Adjusting Tool	
	09213–58012	Crankshaft Pulley Holding Tool	
	09330–00021	Companion Flange Holding Tool	
	09950–40011	Puller B Set	
	(09951–04010)	Hanger 150	Camshaft timing pulley Oil pump drive gear shaft Crank shaft timing gear Injection pump drive gear
	(09952–04010)	Slide Arm	Camshaft timing pulley Oil pump drive gear shaft Crank shaft timing gear Injection pump drive gear
	(09953–04010)	Center Bolt 100	Camshaft timing pulley Oil pump drive gear shaft
	(09953–04020)	Center Bolt 150	Camshaft timing pulley Oil pump drive gear shaft Crank shaft timing gear Injection pump drive gear

	09223–78010	Crankshaft Oil Seal Replacer	Injection pump drive gear oil seal
	09223–00010	Cover & Seal Replacer	
	09214–60010	Crankshaft Pulley & Gear Replacer	Crankshaft pulley
	09268–64010	Injection Nozzle Wrench Set	
	(09268–64020)	Injection Nozzle Holder Retaining Nut Wrench	Injection Nozzle
	09202–70020	Valve Spring Compressor	Valve
	(09202–00010)	Attachment	
	09208–48010	Combustion Chamber Remover	Combustion Chamber
	09201–10000	Valve Guide Bushing Remover & Replacer Set	Valve guide bushing
	(09201–01080)	Valve Guide Bushing Remover & Replacer 8	
	09223–46011	Crankshaft Front Oil Seal Replacer	Camshaft front oil seal
	09222–67011	Connecting Rod Bushing Remover & Replacer	
	(09954–04010)	Arm 25	Camshaft timing pulley Oil pump drive gear shaft Crank shaft timing gear Injection pump drive gear

	(09955–04041)	Claw No.4	
	(09955–04061)	Claw No.6	Camshaft timing pulley Oil pump drive gear shaft Crank shaft timing gear Injection pump drive gear
	09950–50012	Puller C Set	
	(09951–05010)	Hanger 150	Crank shaft pulley Injection pump drive gear
	(09952–05010)	Slide Arm	Crank shaft pulley Injection pump drive gear
	(09953–05010)	Center Bolt 100	Crank shaft pulley Injection pump drive gear
	(09953–05020)	Center Bolt 150	Crank shaft pulley
	(09954–05020)	Claw No.2	Crank shaft pulley Injection pump drive gear
	09960–10010	Variable Pin Wrench Set	
	(09962–01000)	Variable Pin Wrench Arm Assy	Injection pump drive gear No.1 idrer sub–gear
	(09963–00600)	Pin 6	Injection pump drive gear No.1 idrer sub–gear
	09308–10010	Oil Seal Puller	
	09214–76011	Crankshaft Pulley Replacer	Crankshaft from oil seal

	(09222–06031) Base	
	(09222–06020) Guide	
	09223–15030 Oil Seal & Bearing Replacer	
	(09252–10010) No. 1 Replacer Handle	
	(09222–06010) Remover & Replacer	Connecting rod bushing