



STARTING

PP2CY–01

SST (Special Service Tools)

	09201–41020	Valve Stem Oil Seal Replacer	Armature front bearing
	09286–46011	Injection Pump Spline Shaft Puller	Armature rear bearing
	09810–38140	Starter Magnet Switch Nut Wrench 14	
	09950–00020	Bearing Remover	Armature front bearing