CL0BY–01

INSTALLATION

Installation is in the reverse order of removal (See page CL–4).

HINT:

After installation, bleed the system and adjust the clutch pedal.