MT0DP–01

REASSEMBLY

Reassembly is in the reverse order of disassembly (See page MT–11).

HINT:

Coat all of the sliding and rotating surfaces with gear oil before reassembly.