ED037–02

INSPECTION

INSPECT ACCELERATOR PEDAL POSITION SENSOR (See page DI–42)

If necessary, replace the accelerator pedal assembly.