


INJECTION PUMP CORRECTION UNIT

INSPECTION

ED03B–02

INSPECT INJECTION PUMP CORRECTION UNIT (See page DI–69)

If necessary, replace the injection pump assembly (See page FU–8).