INJECTION PUMP

FU06Y–02

ON–VEHICLE INSPECTION

1. INSPECT ENGINE SPEED SENSOR (See page ED–17)
2. INSPECT SPILL CONTROL VALVE (See page ED–9)
3. INSPECT INJECTION PUMP CORRECTION UNIT (See page DI–69)
4. INSPECT TIMING CONTROL VALVE (See page ED–8)