
ENGINE

DI0Z7–04

HOW TO PROCEED WITH TROUBLESHOOTING

When using hand–held tester, troubleshoot in accordance with the procedure on the following pages.



When not using hand–held tester, troubleshoot in accordance with the procedure on the following pages.

