BR0FF–03

REASSEMBLY

Reassembly is in the reverse order of disassembly (See page BR–5).

NOTICE:

Apply iithium soap base glycol grease to the parts indicated by the arrows (See page BR–3).