CL0C3–03

INSTALLATION

Installation is in the reverse order of removal (See page CL–9).

HINT:

After installation, bleed clutch system.