SS0BP–04

TORQUE SPECIFICATION

Part tightened		N·m	kgf·cm	ft·lbf
ATF temperature sensor x Transmission		15	155	11
Detent spring x Valve body		10	100	7
Shift solenoid valve SLT x Valve body		6.4	65	57 in.·lbf
Shift solenoid valve x Valve body	Bolt A	6.4	65	57 in.·lbf
	Bolt B	9.8	100	87 in.·lbf
Valve body x Transmission		11	112	8
Oil strainer x Valve body		11	112	8
Oil pan x Transmission		7.4	75	65 in.·lbf
Drain plug		20	205	15
Oil filler pipe x Transmission		12	120	9
Center exhaust pipe		48	490	35
Front exhaust pipe		43	438	32
Control shaft lever		15.7	160	12
Shift control rod x Shift control lever		13	130	10
Oil cooler pipe clamp		5.0	51	44 in.·lbf
Oil cooler pipe union nut		34	350	25
Stabillizer ber bracket		29	300	22
Stiffener plate		71.5	729	53
Torque converter x Drive plate		41	420	30
No. 2 crossmember x Frame		95	970	70
No. 2 crossmember x Engine rear mounting		13	130	9
Engine mounting x Transmission		40	410	30
Starter x Transmission		39	400	29
Starter wire x Starter		10	102	17
Wire harness x Transmission		8.0	82	71 in.·lbf
Transmission x Engine		71.5	729	53