


Each repair method description provided in Section RE of this manual comprises two pages, divided into 2 blocks (REMOVAL AND INSTALLATION) and includes illustrations to facilitate body repair.



Replacement method
 (ASSY) Assembly replacement
 (CUT) Major cutting (less than 1/2 of parts used)
 (CUT-H) Half cutting (about 1/2 of parts used)
 (CUT-P) Partial cutting (most of parts used)
Replacement Parts

D : REMOVAL GUIDE
Provides additional information to more efficiently help you perform the removal.



- E : INSTALLATION DIAGRAM**
Describes in detail installation of the new parts involving repair by welding and/or cutting, but excluding painting.
- F : INSTALLATION GUIDE**
Provides additional information to more efficiently help you perform the installation.
- G : SYMBOLS**
[See page IN-4.](#)
- H : ILLUSTRATION OF WELD POINTS**
Weld method and panel position symbols.
[See page IN-5.](#)