




## BACK DOOR OPENING REINFORCEMENT (ASSY)


REMOVAL (With the quarter panel removed.)




Back Door Type Spare Wheel Carrier (RH) Only: ● — 1



## INSTALLATION



Back Door Type Spare Wheel Carrier (RH) Only: 1



Seat Belt Anchor Reinforcement (3rd Seat Belt Only)