


INJECTION PUMP (1HZ, 1HD-T)


COMPONENTS

FU05A-01



◆ Non-Reusable Part


B05730




N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-Reusable Part


B05731



B05732



B05733



B05734