



COMPONENTS



No.3 Nozzle Leakage Pipe


 ◆ O-Ring
 137 (1,400, 101)

137 (1,400, 101)

No.3 Cylinder Block Insulator

No.1 Cylinder Block Insulator

No.1 Injection Pump Insulator

◆ O-Ring

Injection Pump Stay

Clamp

Injection Pipe
24.5 (250, 18)

Clamp

Injection Pump Stay Bracket
39 (398, 29)

Clamp


Injection Pump

69 (700, 51)

N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

B05409



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

B05410