


INTAKE HEATER COMPONENTS

ST0F4-01



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

B05334