



CYLINDER HEAD COMPONENTS

EMOTO-01




A04460




A06220





A06047



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

A06107