




INSTALLATION

1. INSTALL REAR WIPER MOTOR AND LINK ASSEMBLY

- (a) Install the wiper link to wiper motor.
- (b) Install the rear wiper motor and link assembly with 3 bolts.
- (c) Connect the connector.

2. INSTALL SERVICE HOLE COVER

Install the service hole cover.

HINT:

Bring out the 2 links through the service hole cover.

3. INSTALL THESE PARTS:

- (a) Back door trim
- (b) Back door garnish
- (c) Assist grip
- (d) Door inside handle

4. INSTALL REAR WIPER ARM

- (a) Install the shaft cover, nut and washer.
 - (b) Operate the wiper once and turn the wiper switch OFF.
 - (c) Install the wiper arm and tighten nut by hand.
 - (d) Adjust the installation position of the wiper arm to the position shown in the illustration.
- A: Approx. 42 ± 10 mm (1.65 ± 0.39 in.)**
B: Approx. 18 ± 10 mm (0.71 ± 0.39 in.)
- (e) Torque the nut.
 - (f) Close the cover.

