

REMOVAL

REMOVE REAR NO.2 SEAT

Remove the 4 bolts and rear No.2 seat.