

INSTALLATION

Installation is in the reverse order of removal ([See page BR-38](#)).

1. AFTER INSTALLATION, FILL BRAKE RESERVOIR WITH BRAKE FLUID AND BLEED BRAKE SYSTEM ([See page BR-5](#) or [BR-10](#))
2. CHECK FOR LEAKS ([See page DI-408](#))